

# Opticon H-15 OS Upgrade Guide

## Step I: Setup

1. Download the latest image file for your device. See the following location.

<http://ftp.opticonusa.com/H15/Software/OS/>

2. Install the file "xip.nb0" onto a micro SD card (FAT format) with capacity no greater than 2GB (only non-HC SD cards supported).
3. Install the SD card under the battery of the H-15 device.
4. Install H-15 battery with at least 30% charge.
5. Install battery door and seal both slide locks.

## Step II: Install OS

1. While holding the keys [F1] and [F4] press [POWER].
2. Release the keys and immediately press and hold the [F1] + [F2] + [F3].
3. The display will read the following:

"Upgrade the system"  
"Please wait..."

4. Wait for the display to read the following text:

"Upgrade successfully"  
"Please reboot system"

## Step III: Hardware Reboot

1. While holding the keys [F1] and [F4] press [POWER].
2. OS will reboot automatically. While booting you will see the following text:

"Loading the OS"  
"Please wait..."